



The effects of iodide on diethylenetriamine (DETA) oxidation

Xinyue Chen

The University of Texas at Austin

Tsinghua University

September 17, 2025



清华大学


Tsinghua University




Outline

- Introduction: inhibition by iodide
- Apparatus
 - High Oxygen Pressure Reactor (HOPR)
 - High Gas Flow reactor (HGF)
- Analytical methods: GC, Peroxide Determination
- Results with DETA
 - HOPR and HGF
 - Peroxide
- Conclusions: iodide decomposes peroxide

DETA has great CO₂ capture performance




Diethylenetriamine
(DETA)




DETA has great performance in biphasic solvents

Solvent	Cyclic capacity (mol/L)
2.5DETA-4TMS	4.5
2DETA-3DGM	3.6
2.6DETA-4.8DMSO	3.4
5MEA	1.6


Amine oxidation leads to environmental impacts and economic pressure.



Iodides can inhibit MEA oxidative degradation – (7 m MEA, 0.4 mM Fe, 0.1 mM Ni, 0.05 mM Cr)




High Oxygen Pressure Reactor (HOPR)






- 300 kPa pure oxygen
- Temperature: 60°C

High Gas Flow reactor (HGF)




Analytical methods

- GC: Amine Retention analysis
- Peroxide Determination: Iodometric titration
 - 2g sample + 20mL 1N H_3PO_4 + 1mL saturated KI + 1mL 1% starch solution
 - Quickly titrate with $\text{Na}_2\text{S}_2\text{O}_3$
 - Detection limit: 0.5 mmol/kg




DETA Retention in HOPR (30 wt% DETA, $\alpha=0.4$, 300 kPa O₂, 60°C)




DETA Retention in HOPR



(30 wt% DETA, $\alpha=0.4$, 300 kPa O₂, 60°C)



NH₃ generation rate of HGF 25 and HGF 26 (30 wt% DETA, $\alpha = 0.4$, 50°C)



Amine oxidation mechanism




- Fenton reaction: $Fe^{2+} + H_2O_2 \rightarrow Fe^{3+} + \cdot OH + OH^-$
- Peroxide also appears in amine without iron.


(Dalmázio, 2008)

(Tachiev, 2000)


Hydrogen peroxide consumption in DETA (30 wt% DETA, $\alpha = 0.4$, 22°C)




Peroxide consumption rate with Ferric in DETA and MEA (30 wt% DETA, 30 wt% MEA, $\alpha = 0.4$, 22°C)




Peroxide consumption rate with iodide in DETA and MEA (30 wt% DETA, 30 wt% MEA, $\alpha = 0.4$, 22°C)



Peroxide consumption with iodide in DETA and MEA (30 wt% DETA, 30 wt% MEA, $\alpha = 0.4$, 25°C)



Peroxide consumption with iodide in DETA and MEA (30 wt% DETA, 30 wt% MEA, $\alpha = 0.4$, 25°C)



Conclusions

- 100 mM Iodide inhibits DETA oxidation **in the absence of Fe^{3+}** .
 - Iodide reacts with peroxide
 - Probably forming non-radical products
 - Terminating radical propagation
- **With Fe^{3+}** , iodide is not effective in DETA but works in MEA.
 - Fe^{3+} in DETA reacts with peroxide faster.
 - But iodide in MEA compete with Fe^{3+} to react with peroxide.
- The effects of iodide depend on the peroxide reaction with iron in amine oxidation.



The University of Texas at Austin
McKetta Department
of Chemical Engineering
Cockrell School of Engineering

Thank You



清华大学
Tsinghua University



Acknowledgements

Texas Carbon Management Program

US Department of Energy

Technology Centre Mongstad

Disclaimer

The Technology Centre Mongstad pilot plant was supported by the U.S. DOE through FE0031861 with additional support from Honeywell UOP and the Texas Carbon Management Program.

One author of this paper consults for a process supplier on the development of amine scrubbing technology. The terms of this arrangement have been reviewed and approved by the University of Texas at Austin in accordance with its policy on objectivity in research. One author also has financial interests in intellectual property owned by the University of Texas that includes ideas reported in this paper.

Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.