

PCCC4 CONFERENCE

HETEROGENEOUS CATALYTIC CO₂- MEA ABSORPTION WITH ALKALINE EARTH METAL CARBONATES;

Huancong Shi, ^{1*}, Yunlong Zhou, ² Raphael Idem,²

Paitoon Tontiwachwuthikul ²

- 1. Department of Environmental Science and Engineering, University of Shanghai for Science and Technology, Shanghai, China 200093
- 2. Clean Energy Technology Research Institute, Faculty of Engineering, University of Regina, Regina SK, Canada
- * Corresponding Author: Huancong shi; Tel 86-13501671535. E-mail address: hcshi@usst.edu.cn

OUTLINE OF THE WORK:

- 1. Background
- 2. Experimental process and chemicals
- 3. Results: Solid chemicals catalysis:
 - 1. 1.0 M MEA solutions. With 0-25g CaCO_3 , MgCO_3 , BaCO_3 .
 - 2. 3.0 M MEA solutions. With 0-25g CaCO_3 , MgCO_3 , BaCO_3 .
- 4. Conclusion

PCCC 4 2017 CONFERENCE

- **Background:**


- Three types of solid alkaline catalysts were selected for CO₂ absorption with MEA solvent. The classic mechanism of “catalytic carbamate formation” was confirmed here, in terms of heterogeneous catalysis. Similar to the aqueous hydroxide [OH⁻] can serve homogeneous catalyst of carbamate formation, several solid alkaline can serve as heterogeneous catalysts/promoters implemented for CO₂ absorption in the amine scrubbing process. The solid catalysts, CaCO₃, MgCO₃ and BaCO₃, can accelerate the CO₂ absorption in MEA solvent properly. These solid alkaline are proved to be good candidates for heterogeneous catalytic CO₂ amine absorption.

EXPERIMENTS AND MATERIALS

- Chemicals and CO₂ loading tests
 - Chemicals, MEA, HCl, CO₂ are commercially available.
 - The solid chemicals were purchased from HuiShan Chemical Ltd; they are magnesium carbonate (MgCO₃), and magnesium carbonate hydroxide (Mg(OH)₂(MgCO₃)₄·5H₂O). The CO₂ gas was purchased from Tansool Chemical Ltd, and the chemicals MEA, HCl and methyl orange were commercial available from Guoyao Chemical Ltd.
- Major Reference
 - Idem, R., Shi, H., Gelowitz, D., Tontiwachwuthikul, P., 2013. Catalytic method and apparatus for separating a gaseous component from an incoming gas stream. US Patent, 2013/0108532 A1.
 - Idem, R., Supap, T., Shi, H., Gelowitz, D., Ball, M.; Campbell, C., Tontiwachwuthikul, P., 2015. Practical experience in post-combustion CO₂ capture using reactive solvents in large pilot and demonstration plants. Int. J. of Greenhouse gas control. 40, 6-25.

EXPERIMENTS AND PROCESS

- Figure 1. Stirred Cell Reactors with suspended fine chemicals:



- From Fig.1 , 0-25 g of pelletized catalysts were wrapped in a net and hang up to the cock during the catalytic reaction. We selected 3 concentrations of MEA, 1, 3, 5 mol/L, with 3 types of solid chemicals CaCO_3 , MgCO_3 and BaCO_3 to conduct the catalytic CO_2 -absorption.

RESULTS. CATALYTIC ABSORPTION WITH SOLID ALKALINE

- 1. CO₂ absorption with 1.0 mol/L MEA solutions with CaCO₃, BaCO₃ and [Mg(OH)₂(MgCO₃)₄·5H₂O]




Fig 2. 1 Catalytic CO₂ absorption of MEA with aid of 5-20g CaCO₃ at 20°C.

RESULTS. CATALYTIC ABSORPTION WITH SOLID ALKALINE

- CO_2 absorption with 1.0 mol/L MEA solutions with CaCO_3 , BaCO_3 and $[\text{Mg}(\text{OH})_2(\text{MgCO}_3)_4 \cdot 5\text{H}_2\text{O}]$




Fig 2. 2 Catalytic CO_2 absorption of MEA with aid of 5-20g BaCO_3 at 20°C.

RESULTS. CATALYTIC ABSORPTION WITH SOLID ALKALINE

- CO₂ absorption with 1.0 mol/L MEA solutions with CaCO₃, BaCO₃ and [Mg(OH)₂(MgCO₃)₄·5H₂O]




Fig 2. 3 Catalytic CO₂ absorption of MEA with aid of 5-20g [Mg(OH)₂(MgCO₃)₄·5H₂O] at 20°C.

RESULTS. CATALYTIC ABSORPTION WITH SOLID ALKALINE

- 2. CO₂ absorption with 3.0 mol/L MEA solutions with CaCO₃, BaCO₃ and MgCO₃




Fig 3. 1 Catalytic CO₂ absorption of MEA with aid of 5-20g CaCO₃ at 20°C.

RESULTS. CATALYTIC ABSORPTION WITH SOLID ALKALINE

- 2. CO₂ absorption with 3.0 mol/L MEA solutions with CaCO₃, BaCO₃ and MgCO₃




Fig 3. 2 Catalytic CO₂ absorption of MEA with aid of 5-25g BaCO₃ at 20°C.

RESULTS. CATALYTIC ABSORPTION WITH SOLID ALKALINE

- 2. CO₂ absorption with 3.0 mol/L MEA solutions with CaCO₃, BaCO₃ and MgCO₃.




Fig 3. 1 Catalytic CO₂ absorption of MEA with aid of 5-20g CaCO₃ at 20°C.

RESULTS. CATALYTIC ABSORPTION WITH SOLID ALKALINE

- 2. CO₂ absorption with 3.0 mol/L MEA solutions with CaCO₃, BaCO₃ and MgCO₃.




Fig 3. 3 Catalytic CO₂ absorption of MEA with aid of 5-20g MgCO₃ at 20°C.

CONCLUSIONS:

- The catalytic effect of solid alkaline onto CO₂-MEA interactions:
- 1 The idea was validated experimentally that pelletized “alkaline earth metal carbonate” can serve as good-performance catalysts for CO₂-MEA absorption. These catalysts were heterogeneous, which are only effective as being placed in the gas-liquid interface with bubbling.
- 2 Three types of solid chemicals were adopted as catalysts for CO₂ absorption with MEA solutions, and 5-20g of MgCO₃ / [Mg(OH)₂(MgCO₃)₄·5H₂O], CaCO₃, and 5-25g BaCO₃ were tested onto MEA solutions under 1, 3 and 5 M concentrations at 20°C.

ACKNOWLEDGEMENT

- This financial supports are provided by Youth Teachers Support Program (ZZsl15042) and Young Eastern Scholar (QD 2016011) with Supporting Funding (10-17-307-005-11). The National Natural Science Foundation of China (NSFC Nos. 21606150) are gratefully acknowledged. Natural Sciences and Engineering Research Council of Canada (Canada) are also acknowledged.

